


MODEL 20405x51D


REPAIR PARTS



1	Housing	776005	13	Nut, Flange	15x84	24	Rod, Pivot	215x17 Z
2	Engine *	*	14	Washer, Belleville	17x137	25	Door, Rear	672613
4	Adjuster, Left Rear Height	672605	15	Washer	17x124	26	Spring	166x44
5	Push On Cap	28x49	16	Bolt	1x153	27	Guard, Rear	671970
6	Bracket, Left Handle	672591	17	Blade	672763E701	28	Wheel	43618
7	Adjuster, Left Front Height	672601	18	Adapter, Blade	672503	29	Bracket, Right Handle	672590
8	Nut, Flange	15x68	19	Adjuster, Right Front Height	672600	30	Adjuster, Right Rear Height	672604
9	Nut, Hex	15x102	20	Bolt, Engine	25x6	31	Screw	26x259
10	Washer	17x38	22	Washer	17x146	32	Guard, Rear	671990
11	Screw	4x21	23	Nut, Flange	15x88	--	Instruction Book	F-99455
12	Hub Cap - Optional	43615						

MODEL 20405x51D

REPAIR PARTS



1	Handle, Upper (Black)	672665E701	12	Guide, Rope	71530	21	Frame, Top	71592
2	Handle, Lower (Black)	671917E701	13	Engine Stop Lever	671924E700	22	Frame Assembly	672614
3	Bolt	2x77	14	Bracket, Stop Lever	43628 BC	23	Bag, Cloth	672110
4	Knob, Plastic	71294	15	Fastener, Cable	71372			
7	Locknut	15x116	16	Engine Stop Cable	672127			
8	Screw	25x14	19	Screw	26x268			
9	Throttle Control	672142	20	Clamp	42294			